


Ford Focus 2011->

Colour: black

Lead Cable for	part-no.:		
Alpine	381114-23-1-1	Kenwood	381114-23-1-7
Blaupunk	381114-23-1-5	Panasonic	381114-23-1-2
Becker	381114-23-1-0	Pioneer	381114-23-1-3
Clarion	381114-23-1-8	Sony	381114-23-1-6
JVC	381114-23-1-9	Zenec	381114-23-1-4

Compatible with these double DIN devices

Double DIN Navigation



© 07/2011 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.

Ford Part-No.: 1519127




1. Ford Foucs OEM Dashboard (sample photo)





2. Unclip panel under OEM radio

3. Remove Panel under OEM radio



4. These 2 screws need to be removed

All installation work must be performed by a qualified professional installer only. The manufacturer / dealer is not liable for any kind of incidential or indirect damages.




60

14. as needed fix speaker with cyanoacrylate adhesive

15. A spare OEM hazard light switch

by Ford is required.

Ford Part-No.: *1519127*



- 5.
 - 5. Unclip OEM panel



16. Mount spare hazard light switch to facia plate. Clip facia plate on dash board. Install everything in reverse order.



6. Remove OEM panel carefully



7. Unplug cables








8. Remove 2 screws (see arrows) Remove OEM head unit



OEM dash board with removed 9. head unit

10. Mount mounting brackets to double DIN head unit





Preperation of facia plate

12. Unclip 2 OEM air vents

Preperation of facia plate

13. Mount them to new facia plate


The Focus is equipped with two kinds of OEM displays

A: Display with 2 buttons at right side (see arrow)

No trim frame required

B: Colour Display:

Clip trim frame to facia plate





11. Install double DIN head unit

Connect all required circuit points and connections. Please see stalk interface manual for connecting stalk interface

Fix navigation with OEM screws



