



Connects2Vision

User Manual

CAM-TY5-AD

Reverse Camera Add On Interface
For select Citroen/Peugeot/Toyota vehicles

APPLICATION:

Citroen C1 (2nd Gen)	2014 - 2021
Peugeot 108	2014 - 2021
Toyota Aygo (AB40)	2014 >

Allows for the addition of an aftermarket reverse camera to the original vehicle screen. This harness works with models which feature factory X-Touch / X-Nav systems.

Note: the camera being paired with this product must be NTSC.

DISCLAIMER:

Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure you use the correct tools to avoid damage to the vehicle or product.

Connects2 can not be held responsible for the installation of this product.

- Reverse Camera Add On Adapter
- 2x Male Bullet Connectors
- Instructions

INSTALLATION

1. Remove the vehicles head unit by following the manufacturer's instructions/guidelines. Once removed, disconnect all the power connections including the 8-pin connector.

2. With the aftermarket camera installed, connect the cameras RCA to the yellow RCA of the CAM-TY5-AD.

3. Connect the red & black 6V wires if the camera being used needs an 6V power supply.

Note: if installing a 12V camera, this will need to be powered by an alternative fused, ignition live 12V power supply from the vehicle.

4. Attach the 8-pin specific connector to the back of the head unit. When done, connect the power and test the reverse camera's functionality before reassembling the dashboard.