


Audi A6(C6/Q3) WIRING DIAGRAM---LDS-A6C6-MINI/LDS-Q3-MINI




DIP SWITCH SETTING

(After changing the dip code,press "reset"or power-on again)

PIN1	PIN2	PIN3	PIN5	CAR MODEL
ON	OFF	OFF	OFF	2010-2012 A6L/A7(C6) 2010-2012 Q7
OFF	OFF	ON	OFF	2009-2018 HIGH-END A4L/A5/Q5
ON	ON	OFF	OFF	High-end 7" A1/Q3
OFF	ON	OFF	OFF	Low-End 6.5" A1/Q3
OFF	OFF	OFF	OFF	USA version A4L/A5/Q5
OFF	OFF	OFF	ON	USA version Q7 (6.5")


PIN4	OFF / ON	NG/NG
PIN6	OFF / ON	NG/NG
PIN7	OFF / ON	NG/Touch point coordinate correction,and turn to "OFF"
PIN8	OFF / ON	NG/NG



Remark:
Pls keep in the original AUX interface when switch to CarPlay interface
(If there is no AUX, pls activate it by computer)



- 1) For A6L/A7 control panel, long press and hold "NAV" button to switch "MENU", long press "NAV" button again, exit the switch MENU.
- 2) Short press "INFO" button to open "Siri".
- 3) Knob to control up/down/right/left/ok.



- 1) For A11/Q3 control panel, long press and hold Voice control button to switch MENU, long press it again to exit the CarPlay Menu
- 2) Short press "Voice control" button to open "Siri"
- 3) Steering wheel Roller to control up/down/ok