


Bei Problemen: überprüfen Sie ob der richtige Adapter verwendet wurde und sich die Verbindungen in den richtigen Steckplätzen befinden. Trennen Sie das Gerät immer von der Spannungsversorgung bevor Sie Änderungen an den Kabeln vornehmen. Überprüfen Sie ob das rote Kabel mit +12V Zündung verbunden ist und nicht mit +12V Dauerplus. Überprüfen Sie die Masseverbindung Ihres Autoradios und vergewissern Sie sich das das schwarze Kabel mit Masse verbunden ist. Überprüfen Sie ob alle Verbindungen genau den in Diagram 1 dargestellten Verbindungen entsprechen.



If Problems: Check that correct adapter has been used and links are in the correct place. Always disconnect from the power supply if you change the head-unit adapter lead. Check that Red wire is 12V ignition and not Permanent power. Check that head-unit is earthed and black wire is earth. Check all connections are the same as the wiring diagram shown here

WÄHLEN SIE HIER DEN ZU IHREM RADIO PASSENDEN ADAPTER AUS

40331 Alpine

1	3	5	7	9	11
2	4	6	8	10	12

40331 Blaupunkt

1	3	5	7	9	11
2	4	6	8	10	12

40331 Clarion

1	3	5	7	9	11
2	4	6	8	10	12

40334 JVC

1	3	5	7	9	11
2	4	6	8	10	12

40335 Kenwood
Single wire

1	3	5	7	9	11
2	4	6	8	10	12

40336 Kenwood
4 pin DIN Plug

1	3	5	7	9	11
2	4	6	8	10	12

40337 Panasonic
Standard CD units

1	3	5	7	9	11
2	4	6	8	10	12

40338 Panasonic
AV head-units

1	3	5	7	9	11
2	4	6	8	10	12

40342 Siemens
VDO

1	3	5	7	9	11
2	4	6	8	10	12

40341 Sony
3v & 5v units

1	3	5	7	9	11
2	4	6	8	10	12

40343 Zenec

1	3	5	7	9	11
2	4	6	8	10	12

40346 Pioneer &
Sony

1	3	5	7	9	11
2	4	6	8	10	12

Special external drive
PCB version

CHOOSE THE CORRECT HEAD-UNIT ADAPTER FROM THOSE BELOW

40331 Alpine

1	3	5	7	9	11
2	4	6	8	10	12

40331 Blaupunkt

1	3	5	7	9	11
2	4	6	8	10	12

40331 Clarion

1	3	5	7	9	11
2	4	6	8	10	12

40334 JVC

1	3	5	7	9	11
2	4	6	8	10	12

40335 Kenwood
Single wire

1	3	5	7	9	11
2	4	6	8	10	12

40336 Kenwood
4 pin DIN Plug

1	3	5	7	9	11
2	4	6	8	10	12

40337 Panasonic
Standard CD units

1	3	5	7	9	11
2	4	6	8	10	12

40338 Panasonic
AV head-units

1	3	5	7	9	11
2	4	6	8	10	12

40342 Siemens
VDO

1	3	5	7	9	11
2	4	6	8	10	12

40341 Sony
3v & 5v units

1	3	5	7	9	11
2	4	6	8	10	12

40343 Zenec

1	3	5	7	9	11
2	4	6	8	10	12

40346 Pioneer &
Sony

1	3	5	7	9	11
2	4	6	8	10	12

Special external drive
PCB version