

CAM-MT2-RT

Reverse Camera Retention Interface For select Toyota & Lexus vehicles

APPLICATION:

Fiat Fullback (2nd Gen/XU30) 2016 - 2019 Mitsubishi L200 2016 - 2019 Mitsubishi Lancer 2008 - 2017 Mitsubishi Outlander 2013 >

Allows for the retention of an OEM reverse camera, or the addition of an aftermarket reverse camera when upgrading to an aftermarket head unit.

Note: when retaining an OEM camera with an aftermarket head unit, it is advised to use a 12V to 6V adapter.

DISCLAIMER:

Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure you use the correct tools to avoid damage to the vehicle or product.

Connects2 can not be held responsible for the installation of this product.

- Reverse Camera Retention Adapter
- Instructions

INSTALLATION

When retaining a factory OEM camera:

- 1. Remove the vehicles head unit by following the manufacturer's instructions/guidelines. Once removed, disconnect all the power connections.
- 2. Connect the 3x Black wires from the CAM-MT2-RT to a chassis ground source.
- 3. Connect the Red wire to a source of accessory power. Note: it is reccommended to use a 12V to 6V voltage dropper in line with this product (sold separately).
- 4. If populated on the factory side, connect the Green/Purple wire to the reverse wire on the aftermarket radio. If not populated, a reverse wire for the radio will need to be sourced from the vehicle.
- 5. Connect the male Yellow RCA jack to the rear camera input of the aftermarket radio. When done, connect the power and test the reverse camera's functionality before reassembling the dashboard.

When adding an aftermarket camera:

- 1. Remove the vehicles head unit by following the manufacturer's instructions/guidelines. Once removed, disconnect all the power connections.
- 2. Connect the 3x Black wires from the CAM-MT2-RT to a chassis ground source.
- 3. Connect the Yellow wire to a source of battery power.
- 4. Conncet the power wire of the aftermarket camera to accessory power.
- 5. Connect the female Yellow RCA of the CAM-MT2-RT to the cameras RCA.
- 6. Connect the male Yellow RCA jack to the rear camera input of the aftermarket radio. When done, connect the power and test the reverse camera's functionality before reassembling the dashboard.